




Item	Qty	Part No.	Name	Additional Info
1	-	46460	Handle Bracket	RFQ - Please Call for Price Quote , RFQ - Please Call for Price Quote
2	-	46412	Hand Lever	(Torque to 4 ft. lbs.) (Pack interior with grease (Mobil 1 Synthetic or equivalent.))
3	-	46461	Handle Bracket	RFQ - Please Call for Price Quote , RFQ - Please Call for Price Quote
4	-	46409	Tie Rod Kit	(Torque to 16 ft. lbs.)
5	-	46414	Relief Valve @ 3000 PSI	(Torque to 30 ft. lbs.)
6	-	46415	Relief Valve @ 2500 PSI	(Torque to 30 ft. lbs.)
7	-	46422	Load Check Valve	(Includes Plastic Plug - All Sections) (Align hole with tie rod and lubricate seal before installation. Push on plastic plug after installation.)
8	-	46434	Feel-To-Float	(Torque two bolts to 4.4 ft. lbs. Torque center bolt to 7 ft. lbs.)
9	-	46413	Spring Centered Spool Control	(Torque four bolts to 4 ft. lbs. Torque center bolt to 7 ft. lbs. Coat spring with grease (Mobil 1 Synthetic or equivalent. Note orientation of spring retainers. Long retainer away from spool.)
10	-	46433	Outlet Section	
11	-	46456	Boom Section	RFQ - Please Call for Price Quote
12	-	46455	Swing Section	RFQ - Please Call for Price Quote
13	-	46429	Stabilizer Sections	
14	-	46428	Bucket and Dipper Sections	
15	-	46419	Inlet Section	(Main Relief Not Included)
16	-	46417	Power Beyond Sleeve	(Optional)
Not Shown	-	46427	Spool Seal Kit	(One Section - Two Seals)
Not Shown	-	46408	Section Seal Kit	(One Section - Four Seals)